### **Bath Pillows**

Use Manual

### **Important**

• Thoroughly inspect your product before proceeding with the use

### Caution

- Read all instructions carefully before use
- Save this manual for future reference.

In keeping with our policy of continuing product improvement, Acritec Industries Corp. reserves the right to change product specifications without notice.



## Installation:

- Clean and dry the bathtub surface.
- Remove the protective film from the back of the pillow.
- Apply the pillow gently in the desired position, pressing from the center towards the edges to help remove air pockets.

# **Removal & Repositioning:**

- Gently pull on one end of the pillow to slowly peel it from the bathtub. Use water as necessary to ease removal.
- Cover the adhesive surface with plastic wrap after removal. This will keep it free of dust and debris.
- Should the adhesive surface lose it's tackiness, reactivate it by rinsing the surface with fresh water and allowing it to air dry.

### **Care and Maintenance:**

- Wash with water and diluted liquid dish soap as necessary. Place the pillow with the adhesive side up and allow it to air dry.
- To store the pillow, apply plastic wrap to the adhesive surface.
- Using the pillow with essential oils, bath salts, or strong detergents will shorten its lifespan.
- Avoid prolonged exposure to UV rays as this may cause discoloration.



To learn more visit us at acritec.com

sales@acritec.com 604.607.0856 Toll free within Canada: 1.877.464.3100

#### ACRITEC INDUSTRIES CORP.

27049 Gloucester Way, Langley, BC Canada V4W 3Y3