

Standard Location of the Air Blower & Jets for Walk In Bathtub

Any deviation of the standard blower location refer to **00156 Custom Pump / Blower Location**



Walk-In

16 Jet Lateral Air System

Standard Location of the Water Pump & Jets for Walk In Bathtub

Any deviation of the standard pump location refer to **00156 Custom Pump / Blower Location**



Walk-In

8 Jet HydroMassage System