




## Installation Instructions for Flanged Tub

1. Set your tub adjacent to its permanent location. Place a protective cover inside the tub to prevent damage during installation to the acrylic surface. Costly to repair!
2. Your tub may have leveling legs or pads for support at the back. If your tub has leveling legs insure that they are firmly in contact with the floor after leveling or the bathtub will squeak and crack when you get in and out. If your bathtub has support pads on a level floor the tub should fit fairly level. If not, level the bathtub with wood shims under the support pads.
3. Check that the water supply lines and sanitary connection are properly roughed-in.
4. Ensure that the floor is firm, squeak-free, and level.
5. Set the tub in place. Confirm that the tub is level from end to end and side to side to ensure proper drainage.
6. Pre-drill the tiling flange at stud locations. Attach the tiling flange to the 2" x 4" studs with coated screws, ensuring that no weight is being carried by the bathtub tiling flange.
7. Install water supply fittings. Connect waste and overflow
8. Drywall can now be installed around the enclosure, butting up to the top of the tiling flange.
9. It's preferable to leave 1/16th" to 1/8th" gap between the tile and tub surface.
10. After installation of wall tiles, apply silicone to the joint between the tub ledge and the tiles.



## Installation Instructions for Double-Flanged Tub

1. Set your tub adjacent to its permanent location. Place a protective cover inside the tub to prevent damage during installation to the acrylic surface. Costly to repair!
2. Your tub may have leveling legs or pads for support at the back. If your tub has leveling legs insure that they are firmly in contact with the floor after leveling or the bathtub will squeak and crack when you get in and out. If your bathtub has support pads on a level floor the tub should fit fairly level. If not, level the bathtub with wood shims under the support pads.
3. Check that the water supply lines and sanitary connection are properly roughed-in.
4. Ensure that the floor is firm, squeak-free, and level.
5. Set the tub in place. Confirm that the tub is level from end to end and side to side to ensure proper drainage.
6. Pre-drill the tiling flange at stud locations. Attach the tiling flange to the 2" x 4" studs with coated screws, ensuring that no weight is being carried by the bathtub tiling flange.
7. Install water supply fittings. Connect waste and overflow
8. Drywall can now be installed around the enclosure, butting up to the top of the tiling flange.
9. It's preferable to leave 1/16th" to 1/8th" gap between the tile and tub surface.
10. After installation of wall tiles, apply silicone to the joint between the tub ledge and the tiles.

